


1 Turn the LIVEN 8bit warps on.

1 Supply power in one of these ways.

- Install 6 AA batteries in the battery compartment on the bottom.
- Connect an AC adapter with DC9V output (1A or higher, EIAJ3 standard, 1.7mm inside diameter, 4.75mm, outside diameter, center +). ※

※Always use an AC adapter with these specifications. Using an AC adapter with different specifications could cause damage.

2 Press and hold the POWER switch to turn the unit on.



2 Play a variety of sounds.


- 1 Press the MEM button.
- 2 Press the Page and Step buttons to select sounds.
- 3 Turn the VOL knob to adjust the volume.

3 Alter a sound.

- 1 While pressing the func button, press the WARP, ATTACK, MORPH or FM button to select the synthesizer engine.
- 2 Turn the knobs to adjust the parameters.

4 Listen to a variety of patterns.

- 1 Press the PTN button.
- 2 Press the Page and Step buttons to select patterns.
- 3 Press the ► button.
- 4 Turn the TEMPO knob to adjust the tempo.



Visit our website for detailed use instructions and the latest information.

www.sonicware.jp