


# SONICWARE ELZ.1 Start Up Guide

## 1 Turn on the ELZ.1

- 1 Install batteries or connect the included USB cable to an AC adapter with USB output.



Use a USB AC adapter that has an output current of at least 2000 mA.

- 2 Press and hold the **POWER switch** to turn the unit on

### HINT


The included USB cable can be connected to a mobile battery instead of a USB AC adapter.

## 2 Test a variety of sounds

- 1 Use **MEMORY -** and **+** to load the desired sound setting.
- 2 Turn the **VOL knob** to adjust the volume

### HINT

The **MEMORY** can save 128 settings, numbered 0-127. Preset sounds are included at the time of purchase. Use to change the keyboard octave.



## 3 Edit sounds

- 1 Press  to enter oscillator mode
- 2 Turn **TYPE** to select the synthesizer engine
- 3 Turn **1, 2, 3 and 4** to adjust the parameters
- 4 Check the various parameter values on the screen
- 5 Other modes can be edited in the same manner

### HINT

- If there are five or more parameters, press the mode key again to show additional parameters that can be adjusted.
- In effect mode, press  again to change the effect module.
- Parameter changes will not be saved if the **MEMORY** setting is changed or the power is turned off. Press  to save changes as necessary.

